

# QUALICARB DUO

Thermowelded & carbon block cartridge

## Description

QUALICARB DUO was designed to optimize filtration stages , it is placed uphill from an extruded carbon cartridge in order to enhance the reduction of a pollutant (chlorine) or downhill from a thermowelded cartridge in order to create a finer filtration.

QUALICARB DUO is used for residential applications under a sink or uphill from a purification device (osmosis unit,UF...) and specific purification processes (surface treatment, deodorizing...)



## Characteristics & advantages

- Nominal prefiltration at 5µm
- Adsorption on GAC extruded compacted carbon
- Coconut carbon
- Available on request with 3,7, and 8 fittings
- Length from 10" to 30"

## Dimensions

Outer diameter	63 mm
Inner diameter	28 mm
Length	10" up to 30"

## Technical features

<b>Max temperature</b>	65°C
<b>Flowrate</b>	from 250L/h up to 300L/h max / 9"3/4
<b>Pressure drop</b>	Initial DeltaP at 3,8L/min or 240L/h 250 mbars by 10
<b>Max differential pressure</b>	3.4 bars at 50°C

# QUALICARB DUO

Thermowelded & carbon block cartridge

## Reference order

REFERENCE QCD - **05** - **20**  
Tab 1 Tab 2

**Table 1 : Prefiltration**

Code	Description
05	5 µm

**Table 2 : Length**

Code	Description
10	10 " = 254 mm
20	20 " = 508 mm
30	30 " = 762 mm



**SIEBEC SAS** - 9 rue des platanes, 38120 Saint-Égrève - Tel. : +33 4 76 26 12 09 - [contact@siebec.com](mailto:contact@siebec.com)

**SIEBEC UK LTD** - Unit 3, St. Alban's Rd, Stafford ST16 3DR - Tel. : +44 1 785 227 700 - [sales@siebec.co.uk](mailto:sales@siebec.co.uk)

**P.G SIEBEC SL** - Enric Morera, 14 4<sup>a</sup>, 08950 Esplugues de Llobregat - Tel. : +34 933 722 024 - [ventas@siebec.com](mailto:ventas@siebec.com)

**SIEBEC GmbH** - Auf der Langwies 8, 65510 Hünstetten-Wallbach - Tel. : +49 6126 9384-19 - [info@siebecgmbh.de](mailto:info@siebecgmbh.de)